



HOT WIRE (RED)

GROUND (GREEN)

BARE WIRE TO GROUND

When installing make sure the wire exiting the pickup is on the High E side